


How to replace the blade



Mountain-shaped blade
(Replacement blade model code: TC-C)

- ① Loosen two screws after unlocking the safety lock.
- ② Take the blade out from the blade groove.
- ③ Rotate the blade by 180° to use other side of it.
- ④ Install it into the blade groove by holding the hexagonal hole of the blade.
- ⑤ Tighten the screws until the blade is fixed properly.
(Recommended tightening torque: 0.4Nm)